



Special measures specified in the form of Hand Dig (e.g. hand tools only) within the RPAs to protect tree roots

Special measures specified in the form of No Dig (e.g. Cellweb) within the RPAs to protect tree roots

Special measures specified in the form of Ground Protection Area within the RPAs to protect tree roots, whilst providing working space

- Category A crown
- Category B crown
- Category C crown
- Root Protection Area
- Veteran Root Protection Area
- Protective Barrier
- No Dig Area
- Hand Dig Area
- Ground Protection Area
- Tree to be removed shown as dotted crown (colour according to category)